




Please leave this form with product once installed.


PLEASE INSPECT PRODUCT PRIOR TO INSTALLING. Carefully review all pre-assembled parts. It will be necessary for the various parts to be re-assembled exactly as shown. NOTICE: These instructions do not represent step-by-step directions. They are a product supplement only to be used by a qualified/licensed plumber. We recommend all plumbing fixtures be installed by a professional.

Care Instructions:

The product you have just purchased is designed to provide you with long lasting beauty and dependability. To ensure your product's longevity, please follow the following care instructions.

When installing, we recommend you lay all parts on a soft cloth or towel to avoid scratching or damaging the product. To care for your fitting, wipe with a clean, soft, damp cloth and blot dry as often as possible. Never use abrasive cleansers, sponges, or acidic cleaning products as these may damage the finish and may VOID THE WARRANTY.











Please leave this form with product once installed.

8" VERSION BOTTOM VIEW



INSTALLER NOTE:
THE ALIGNMENT OF THE
FAUCET TRIM WITH THE
ROUGH-IN BOX WILL VARY FOR
THE 8" AND 11" VERSIONS.
CAREFULLY CHECK
THE ASSEMBLED DIMENSIONS
BEFORE INSTALLATION.

11" VERSION BOTTOM VIEW








Please leave this form with product once installed.

Step 1: Cut a 2 x 4 to the length of the distance in-between your in-wall studs. Install the 2 x 4 in-between the in-wall studs to use as a mounting board. Note: install the mounting board at the correct distance so Rough-in box will not be installed any further than 1-1/4" behind finished wall. Using screws or nuts and bolts (supplied by others), install Rough-in Box to correct depth. Rough-in Box cannot be installed further than1-1/4" behind finished wall.

After Rough-in Box is mounted level, plumb in the hot and cold inlets. See Page (6) for Full Scale cut out template for finished wall hole needed for trim installation.


FRONT VIEW (ROUGH-IN BOX) TOP VIEW (ROUGH-IN BOX) 2 x 4 3" WOOD SCREWS SHOWN. MOUNTING HARDWARE MAY VARY. (SUPPLIED BUY OTHERS) Mounting **Board** In-wall In-wall 14-1/2" TYPICAL DISTANCE IN-BETWEEN WALL STUDS LENGTH WILL VARY Stud Stud 1/2" NPT COLD INLET 1/2" NPT HOT INLET 3/4" 2-1/4" 1-1/4" Mounting holes to secure rough-in box to 2x4 Mounting Board. See provided Finished Note: Installer the Rough-in Box cutout template Wall cannot be installed any further NO HEAT NO for wall hole than 1-1/4" behind finished wall. needed for TORCH installation







Please leave this form with product once installed.








Please leave this form with product once installed.

Step 4: Use a 2.5mm hex wrench to tighten the 2 provided set screws onto the pegs that are pre-installed onto the back plate to secure the body onto the back plate.

BOTTOM VIEW



AMERICAN

AMERICAN FAUCET & COATINGS CORPORATION LIMITED PRODUCT WARRANTY

AMERICAN

Product/Finish Warranty: American Faucet & Coatings Corporation warrants that products are free from defects in materials and workmanship for five (5) years from date of invoice. In addition, our Finish Warranty provides limited LIFETIME coverage for Chrome & PVD finishes, five (5) years for Omega powder coated finishes. Living finishes are war-ranted for workmanship only. If any material proves to be defective after inspection by our company, it will be repaired or replaced at our discretion at no charge. However, no claims for labor, shipping costs, or consequential damages will be accepted.

What we will do: We will restore any product whose finish proves to be defective back to its original finish at no charge during the appropriate warranty period stated above. Proof of purchase must be provided. After the warranty period, American Faucet and Coatings Corporation will refinish any of its faucets at the prevailing appropriate charge.

What you must do: The faucets must be properly installed according to our instructions and specifications & are for residential use only. The faucets cannot be altered in any way. You must maintain and clean the faucets in accordance with the instructions provided with the product. You must use the faucet(s) for residential use only.

How to obtain service: Contact our customer service by calling 800.960.BATH or send an email to customerservice@sigmafaucet.com. Please have you model number and proof of purchase available so we can better assist you.

We will then respond and take appropriate action. Do not send us any part(s) of your faucet(s) or its various connecting hoses unless we have contacted you and have sent you an approved RGA form. All transportation charges for returned goods must be paid by the customer.

What is not covered: This warranty does not cover the crystal/glass, or porcelain products of any faucet or the drain assembly or aerator on other than the Chrome or PVD finishes. This warranty also does not cover damage caused by accident, alterations, misuse, abuse, normal wear and tear, lime deposits, direct exposure to salty air or corrosive materials, or the color change that takes place with the passage of time, or use in any manner contrary to American Faucet and Coatings Corporation's printed instructions. In the case of in-the-wall installations American Faucet and Coatings Corp. will assume no liability if there is no access. In no event will we be liable for labor of any kind, incidental or consequential damages. This warranty is extended in lieu of all other expressed or implied warranties, whether oral or written. Many installation compounds are harmful to brass and metal finishes. The use of any lead-based or acidic curing adhesive, silicone, mastic, or plumber's putty on or near our finished products will void the finish warranty. Use only sealants which are neutral curing and are not reactive with metal and brass finishes. American Faucet & Coatings Corporation reserves the right to change, modify or alter its products as deemed necessary. This warranty super-sedes any other American Faucet & Coatings Corporation warranties, whether oral or written.

Unless otherwise contrary to state law governing the purchase, American Faucet and Coatings Corporation's liability will not exceed the wholesale price for the American Faucet and Coatings Corporation product considered defective. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow exclusion of incidental or consequential damages, so the above limitation may not apply to you.

LIFETIME WARRANTY ON 1/4 TURN CERAMIC DISC CARTRIDGE

Should the ceramic disc cartridge in your faucet ever fail, American Faucet & Coatings Corporation will replace the failed part free of charge to the original purchaser of the product. Shipping and handling charges will apply. Labor not included. When ordering replacements, denote for widespread or centerset lavatory, Roman Tub, or other. Include age of faucet. (This does not include thermostatic, pressure balance, or diverter cartridges.)

CONSUMER WARNING CALIFORNIA PROPOSTION 65 WARNING

Among other chemicals known to cause harm, this faucet contains lead, a chemical known to the State of California to cause birth defects or other reproductive harm.

All faucets and products made of leaded brass alloys, even those that comply with U.S. Environmental Protection Agency regulations, contribute small amounts of lead to water that is allowed to stand in contact with the brass. This faucet complies with all E.P.A. regulations regarding the amount of lead used in plumbing brass and solder. The amount of lead contributed by any faucet is highest when the faucet is new. The following steps will reduce potential for exposure to lead from faucets and other parts of the plumbing system:

- Always run the water for a few seconds prior to use for drinking or cooking.
- Use only cold water for drinking or cooking.
- If you wish to flush the entire plumbing system of water that has been standing in the pipes or other fittings, run the cold water until the temperature of the water drops, indicating water coming from the outside main.
- If you are concerned about lead in your water, have your water tested.

